




**Constant Control**  
**Ordering Code: N**




**RJ45 Connector**  
**Ordering Code: R**



**XLR Connector**  
**Ordering Code: X**



**Insulation Displacement  
 Connector Ordering Code: I**



**Screw Terminal  
 Connector Ordering Code: ST**